







Push Connect Brass Fittings

Description	Part No.	Tube	NPT
 Male Rigid Elbow	ABPC9M-4A	1/4	1/8
	ABPC9M-4B	1/4	1/4
	ABPC9M-6B	3/8	1/4
	ABPC9M-6C	3/8	3/8
 Male Swivel Elbow	ABPC9MS-2B	1/8	1/4
	ABPC9MS-4A	1/4	1/8
	ABPC9MS-4B	1/4	1/4
	ABPC9MS-4C	1/4	3/8
	ABPC9MS-6B	3/8	1/8
	ABPC9MS-6C	3/8	1/4
	ABPC9MS-6D	3/8	3/8
	ABPC9MS-8B	1/2	1/4
	ABPC9MS-8C	1/2	3/8
	ABPC9MS-8D	1/2	1/2
 Male Swivel Run Tee	ABPCRTS-4A	1/4	1/8
	ABPCRTS-4B	1/4	1/4
	ABPCRTS-6B	3/8	1/4
	ABPCRTS-6C	3/8	3/8
	ABPCRTS-6D	3/8	1/2
	ABPCRTS-8B	1/2	1/4
	ABPCRTS-8C	1/2	3/8
	ABPCRTS-8D	1/2	1/2

Description	Part No.	Tube	NPT
 Female Swivel Elbow	ABPC9FS-4A	1/4	1/8
	ABPC9FS-4B	1/4	1/4
	ABPC9FS-6A	3/8	1/8
	ABPC9FS-6B	3/8	1/4
 Male Connector	ABPCM-4A	1/4	1/8
	ABPCM-4B	1/4	1/4
	ABPCM-4C	1/4	3/8
	ABPCM-6A	3/8	1/8
	ABPCM-6B	3/8	1/4
	ABPCM-6C	3/8	3/8
	ABPCM-8B	1/2	1/4
	ABPCM-8C	1/2	3/8
 Male Swivel Branch Tee	ABPCBTS-4A	1/4	1/8
	ABPCBTS-4B	1/4	1/4
	ABPCBTS-6B	3/8	1/4
	ABPCBTS-6C	3/8	3/8
	ABPCBTS-6D	3/8	1/2
	ABPCBTS-8B	1/2	1/4
	ABPCBTS-8C	1/2	3/8
	ABPCBTS-8D	1/2	1/2

Application: Used with nylon, polyurethane or polyethylene in compressed air or water applications.

Working Pressure: 0 to 150 psi, reference to pressure on tube being used

Temperature Range: 0 ° to 60 °C depending on hose

Recommended Assembly:

1. To Connect Tube

Install male or female pipe end (if applicable). Cut tube square, Insert tube in fitting until it bottoms on stop

2. To Disconnect Tube

Reduce line pressure to zero. Push tube against stop (towards fitting). Push in and hold release ring and pull tubing out


Push Connect Brass Fittings




Description	Part No.	Tube Size
Union - Tube Both Ends	ABPCU-4	1/4
	ABPCU-6	3/8
	ABPCU-8	1/2
Union Tee - All Ends	ABPCUT-4	1/4
	ABPCUT-6	3/8
	ABPCUT-8	1/2
Bulkhead Union	ABPCBHU-4	1/4
	ABPCBHU-6	3/8
	ABPCBHU-8	1/2

Description	Part No.	Tube Size
Union Elbow 90°- Tube Both Ends	ABPCU9-4	1/4
	ABPCU9-6	3/8
	ABPCU9-8	1/2
In Line Check Valve - All Ends	ABPCCV-4	1/4
	ABPCCV-6	3/8
	ABPCCV-8	1/2
Plug In Reducer – FTG x Tube	ABPCR-4-2	1/4 x 1/8
	ABPCR-6-4	3/8 x 1/4
	ABPCR-8-4	1/2 x 1/4
	ABPCR-8-6	1/2 x 3/8



Female Bulkhead	Part No.	Tube	FPT
	ABPCBHF-4A	1/4	1/8
	ABPCBHF-4B	1/4	1/4
	ABPCBHF-4C	1/4	3/8
	ABPCBHF-6A	3/8	1/8
	ABPCBHF-6B	3/8	1/4
	ABPCBHF-6C	3/8	3/8
	ABPCBHF-6D	3/8	1/2
	ABPCBHF-8B	1/2	1/4
	ABPCBHF-8C	1/2	3/8
	ABPCBHF-8D	1/2	1/2

Female Connector	Part No.	Tube	FPT
	ABPCF-4A	1/4	1/8
	ABPCF-4B	1/4	1/4
	ABPCF-4C	1/4	3/8
	ABPCF-6A	3/8	1/8
	ABPCF-6B	3/8	1/4
	ABPCF-6C	3/8	3/8
	ABPCF-6D	3/8	1/2
	ABPCF-8B	1/2	1/4
	ABPCF-8C	1/2	3/8
	ABPCF-8D	1/2	1/2